

User Manual IPM-04 PDU management software

W series PDU : **Single Phase 250V**
Three Phase 400V



Designed and manufactured by Austin Hughes

FC CE  REACH

Legal Information

First English printing, October 2002

Information in this document has been carefully checked for accuracy; however, no guarantee is given to the correctness of the contents. The information in this document is subject to change without notice. We are not liable for any injury or loss that results from the use of this equipment.

Safety Instructions

Please read all of these instructions carefully before you use the device. Save this manual for future reference.

- Unplug equipment before cleaning. Don't use liquid or spray detergent; use a moist cloth.
- Keep equipment away from excessive humidity and heat. Preferably, keep it in an air-conditioned environment with temperatures not exceeding 40° Celsius (104° Fahrenheit).
- When installing, place the equipment on a sturdy, level surface to prevent it from accidentally falling and causing damage to other equipment or injury to persons nearby.
- When the equipment is in an open position, do not cover, block or in any way obstruct the gap between it and the power supply. Proper air convection is necessary to keep it from overheating.
- Arrange the equipment's power cord in such a way that others won't trip or fall over it.
- If you are using a power cord that didn't ship with the equipment, ensure that it is rated for the voltage and current labelled on the equipment's electrical ratings label. The voltage rating on the cord should be higher than the one listed on the equipment's ratings label.
- Observe all precautions and warnings attached to the equipment.
- If you don't intend on using the equipment for a long time, disconnect it from the power outlet to prevent being damaged by transient over-voltage.
- Keep all liquids away from the equipment to minimize the risk of accidental spillage. Liquid spilled on to the power supply or on other hardware may cause damage, fire or electrical shock.
- Only qualified service personnel should open the chassis. Opening it yourself could damage the equipment and invalidate its warranty.
- If any part of the equipment becomes damaged or stops functioning, have it checked by qualified service personnel.

What the warranty does not cover

- Any product, on which the serial number has been defaced, modified or removed.
- Damage, deterioration or malfunction resulting from:
 - ☐ Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
 - ☐ Repair or attempted repair by anyone not authorized by us.
 - ☐ Any damage of the product due to shipment.
 - ☐ Removal or installation of the product.
 - ☐ Causes external to the product, such as electric power fluctuation or failure.
 - ☐ Use of supplies or parts not meeting our specifications.
 - ☐ Normal wear and tear.
 - ☐ Any other causes which does not relate to a product defect.
- Removal, installation, and set-up service charges.

Regulatory Notices Federal Communications Commission (FCC)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

Any changes or modifications made to this equipment may void the user's authority to operate this equipment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-position or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Unpacking

The equipment comes with the standard parts shown on the package contents. Check and make sure they are included and in good condition. If anything is missing, or damage, contact the supplier immediately.



All electrical power and power control wiring must be installed by a qualified electrician and comply with local and national regulations.




Don't exceed the outlet, branch or phase limitations


Power ON

- Connect the PDU into an appropriately rated receptacle
- When the PDU is power on, the LED display will light up. That means all outlets are activated
- Keep the equipments in the power off position until it is plugged into the PDU

Tips for hardware Installation



Tips for System Setup



Content

Part I. “ W “ Meter		Page
< 1.1 >	Meter Key Features	1
< 1.2 >	Meter Reading & Setting - Single Phase PDU	3
< 1.3 >	Meter Reading & Setting - Three Phase PDU	7
< 1.4 >	Meter (PDU) Cascade	12
< 1.5 >	IP Dongle Installation	13
< 1.6 >	Meter System Timer	14
< 1.7 >	Optional Accessory - Temp. Sensor / Temp. + Humidity Sensor	15
	- Extended Door-mount Amp / Temp. Display	17
Part II. Software		
< 2.1 >	Key Features	19
< 2.2 >	IP Dongle Configuration	20
< 2.3 >	Hardware Requirements of the Management PC	21
< 2.4 >	Supported OS Platform & Language	21
< 2.5 >	Software Download	22
< 2.6 >	First Time Start-up Setting	23
< 2.7 >	Web Server Port no. Change	25
Part III. System Setup & Remote Access		
< 3.1 >	System Setup	26
< 3.2 >	Remote Access	32
Part IV. Software Usage & Operation		
< 4.1 >	Status	33
< 4.2 >	Details	34
< 4.3 >	Outlet Setting	35
< 4.4 >	Sensor status	36
< 4.5 >	Sensor setting	37
< 4.6 >	Outlet Schedule Overview	38
< 4.7 >	Outlet Schedule Setting	39

Content

Part V. Log & Events	Page
< 5.1 > Single Phase PDU / Outlet Log	43
< 5.2 > Three Phase PDU / Outlet Log	47
< 5.3 > Sensor Log	49
< 5.4 > Event Log	50
 Part VI. Report	 51
 Part VII. SNMP	
< 7.1 > SNMP Setup via IP Dongle	52
< 7.2 > IP Dongle Firmware Upgrade	54
 Part VIII. FAQ	
< 8.1 > Management Software	56
< 8.2 > IP Dongle	58
< 8.3 > W Meter	60
< 8.4 > Power Module	62
< 8.5 > Outlet Control Module	62
< 8.6 > TH Sensors & Others	63

Part I. “ W “ Meter

< 1.1 > Meter Key Features

Four intelligent PDU series covering single & three phase equipped with W Meter :

Monitored PDU : ① W PDU
② Wi PDU - Outlet Measurement

Switched PDU : ③ WS PDU
④ WSi PDU - Outlet Measurement

InfraPower®	Monitored PDU		Switched PDU	
	W	Wi	WS	WSi
Outlet Amp + kWh Measurement		✓		✓
Outlet Switch ON / OFF			✓	✓
Field Replaceable Meter	✓	✓	✓	✓
2.8” Color LCD (featured w/ Touchscreen)	✓	✓	✓	✓
Circuit / Phase Amp + kWh Measurement	✓	✓	✓	✓
Support Single & Three Phase PDU	✓	✓	✓	✓
Phase Balance % (3 Phase PDU only)	✓	✓	✓	✓
Temp-Humid Sensor port x 2	✓	✓	✓	✓
16 PDU Levels in Single Daisy Chain	✓	✓	✓	✓
One IP Access up to 16 PDU Levels	✓	✓	✓	✓
Tool-less Mounting for Vertical PDU	✓	✓	✓	✓
SNMP Capability via IP Dongle	✓	✓	✓	✓
Free Management Software (via PDU IP Dongle, IPD-04S)	IPM-04	IPM-04	IPM-04	IPM-04

W series PDU is equipped with a highly advanced component - “ W “ Meter .

- Single & Three Phase PDU can be inter-cascaded in a single daisy chain.
- Simply connect 1 x IP Dongle to access up to 16 PDUs to save IP network address.
- SNMP Capability via IP Dongle
- Built-in buzzer will sound when circuit or bank Amp over alarm setting.
- Field replaceable design allows meter replacement without PDU power interruption.

1 Cascade port
Up to 16 PDU Level

2 Sensor port x 2
- Temp. Sensor
- Temp. + Humid. Sensor

3 2.8” color LCD
Featured w/ Touchscreen

4 Reset button
To re-power the meter if necessary but won't
cause any change on settings and memories.




< 1.2 > Meter Reading & Setting

Reading < Single Phase PDU >

- Amp, Voltage & Power Factor
- kWh Energy Consumption
- Active & Apparent Power
- Temp. & Humidity

Touch Button
(Single & Dual Circuit)



Single Circuit

1 - 3

◀ Main ▶

Amp 15.9

kW 1.80

Volt 226.2

T1 23.4 T2 24.5 °C

M

4 - 7

◀ Power ▶

Factor 0.50

Active 1.80 kW

Apparent 3.60 kVA

299,678.56 kWh

1 Jan 15 / 23 : 59 : 40

M

◀ PDU ID ▶

Group : 050

Level : 16

M

◀ TH ▶

T1 23.4 °C

T2 24.5

H1 63.4 %

H2 56.5

M

◀ Circuit A ▶

15.9 Amp

Peak Load Amp 16.2

1 Jan 15 / 23 : 59 : 40

M

◀ System ▶

Time 23 : 59 : 40

Date 15 Jan 15

F/W WSi-1B-V5

Serial no. 20315150589-1120-P001

Model no. V24C13/12C19 -16A-WSi/CR_EN/3B-1

M

◀ Outlet ▶

◀ 01 ▶

Amp 10.9

kW 1.23

Page no.5
Touch °C / °F to change temp. unit

Page no.7
Wi / WSi outlet measurement PDU only

Dual Circuit

1 - 4

◀ Main ▶

Amp 31.7

A 15.9

B 15.8

kW 3.58

Volt 226.2

T1 23.4 T2 24.5 °C

M A B

5 - 8

◀ Power ▶

Factor 0.50

Active 03.58 kW

Apparent 07.16 kVA

299,678.56 kWh

1 Jan 15 / 23 : 59 : 40

M A B

◀ PDU ID ▶

Group : 050

Level : 16

M A B

◀ TH ▶

T1 23.4 °C

T2 24.5

H1 63.4 %

H2 56.5

M A B

◀ Circuit A ▶

15.9 Amp

Peak Load Amp 16.2

1 Jan 15 / 23 : 59 : 40

M A B

◀ System ▶

Time 23 : 59 : 40

Date 15 Jan 15

F/W WSi-2B-V5

Serial no. 20315150589-1120-P001

Model no. V24C13/12C19 -32A-WSi/CR_EN/3B-1

M A B

◀ Circuit B ▶

15.8 Amp

Peak Load Amp 16.2

1 Jan 15 / 23 : 59 : 40

M A B

◀ Outlet ▶

Cir. A

◀ 01 ▶

Amp 10.9


kW 1.23

A B

Page no.6
Touch °C / °F to change temp. unit

Page no.8
Wi / WSi outlet measurement PDU only

Touch Button
(63A)



63A

1 - 2

◀ Main ▶

Amp	63.0
B1	15.8
B2	15.7
B3	14.6
B4	16.9
kW	7.18
Volt	228.0

T1 23.4 T2 24.5 °C

◀ PDU ID ▶

Group : 050

Level : 16

M B1 B2 B3 B4

3 - 6

◀ Circuit B1 ▶

15.8 Amp

Peak Load Amp 16.2
1 Jan 15 / 23:59:40

M B1 B2 B3 B4

◀ Circuit B2 ▶

15.7 Amp

Peak Load Amp 16.2
1 Jan 15 / 23:59:40

M B1 B2 B3 B4

◀ Circuit B3 ▶

14.6 Amp

Peak Load Amp 16.2
1 Jan 15 / 23:59:40

M B1 B2 B3 B4

◀ Circuit B4 ▶

16.9 Amp

Peak Load Amp 17.2
1 Jan 15 / 23:59:40

M B1 B2 B3 B4

7 - 10

◀ Power ▶

Factor	0.50
Active	07.18 kW
Apparent	14.36 kVA

299,678.56 kWh
1 Jan 15 / 23:59:40

M B1 B2 B3 B4

◀ T H ▶

T1	23.4 °C
T2	24.5
H1	63.4 %
H2	56.5

M B1 B2 B3 B4

◀ System ▶

Time	23:59:40
Date	15 Jan 15
F/W	WSI-4B-V5
Serial no.	20315150589-1120-P001
Model no.	V24C13/12C19 -63A-WSI/CR_EN/3B-1

M B1 B2 B3 B4

◀ Outlet ▶

B1

◀ 01 ▶

Amp	10.9
kW	1.24

B1 B2 B3 B4

Page no.8


Touch °C / °F to change temp. unit

Page no.10


Wi / WSi outlet measurement PDU only

< 1.2 > Meter Reading & Setting


Setting < Single Phase PDU >



Monitored PDU




Switched PDU




PDU Level Setting

Default no. : 16



Buzzer ON / OFF

Default : ON




Default : Screen < ON > Scan < OFF >

* OFF Screen :

- Screen OFF in 30 seconds
- If want to turn on the screen just touch it
- OFF in 30 seconds if no any further touch

* ON Scan :


- Scanning starts in 30 seconds
- Then scan each page per 3 seconds



Outlet ON / OFF




Default : ON

WS / WSi Switched PDU only



Touchscreen Calibration

If no any calibrate touch in 30 seconds, it will return to Touchscreen page




< 1.3 > Meter Reading & Setting

Reading < Three Phase PDU >

- Amp, Voltage & Power Factor
- kWh Energy Consumption
- Active & Apparent Power
- Phase Balance
- Temp. & Humidity

Touch Button



Three Phase 16A / 32A

1 - 3

◀ Main ▶

	Amp	Volt
L 1	22.5	226.2
L 2	13.8	219.2
L 3	8.2	223.2
T1	23.4	T2 24.5 °C

M

L1

L2

L3

◀ PDU ID ▶

Group : 050

Level : 16

M

4-5

◀ Volt / Bal ▶

Volt	226.2	L1
	219.2	L2
	223.2	L3
Bal %	101.5	L1
	98.3	L2
	100.1	L3

M

◀ Power ▶

Factor	0.50
Active	4.97 kW
Apparent	9.94 kVA
299,678.56 kWh	
1 Jan 15 / 23 : 59 : 40	

M

6 - 8

◀ T H ▶

T1	23.4 °C
T2	24.5
H1	63.4 %
H2	56.5

M

◀ System ▶

Time 23 : 59 : 40

Date 15 Jan 15

F/W WSi-400V-6B-V5

Serial no.
20315150589-1120-P001

Model no.
VP24C13/12C19
-32A-WSi/CR_EN/2B-1

M

32A Bank x 6

◀ Amp ▶

L 1	16.0	B1
	6.5	B2
L 2	8.0	B3
	5.8	B4
L 3	5.0	B5
	3.2	B6

M

16A Bank x 3

◀ Amp ▶

L 1	16.0	B1
L 2	8.0	B2
L 3	5.0	B3

M

32A Bank x 6

◀ Outlet ▶

B1

◀ 01 ▶

Amp 10.9

kW 1.23

B1	B3	B5
B2	B4	B6

16A Bank x 3

◀ Outlet ▶

B1

◀ 01 ▶

Amp 10.9

kW 1.23

B1	B2	B3
----	----	----

Page no.6
Touch °C / °F
to change
temp. unit


Page no.8
Wi / WSi outlet
measurement
PDU only

UM-IPM-04-250V-400V-Q215V1

P.7

www.austin-hughes.com

Phase Reading (400V, 32A, Bank x 6)




Phase Reading (400V, 16A, Bank x 3)



< 1.3 > Meter Reading & Setting

Reading < Three Phase PDU >

Touch Button



Three Phase 63A

1 - 3

◀ Main ▶

	Amp	Volt
L 1	60.0	226.2
L 2	59.0	219.2
L 3	63.0	223.2

T1 23.4 T2 24.5 °C

M
L1
L2
L3

◀ PDU ID ▶

Group : 050

Level : 16

M

◀ Amp ▶

L 1	31.0	B1
	29.0	B2
L 2	28.0	B3
	31.0	B4
L 3	31.5	B5
	31.5	B6

M

4

◀ Volt / Bal ▶

Volt	226.2	L1
	219.2	L2
	223.2	L3
Bal %	101.5	L1
	98.3	L2
	100.1	L3

M

5 - 8

◀ Power ▶

Factor 0.50

Active 20.29 kW

Apparent 40.58 kVA

299,678.56 kWh

1 Jan 15 / 23 : 59 : 40

M

◀ TH ▶

T1 23.4 °C

T2 24.5

H1 63.4 %

H2 56.5

M

◀ System ▶

Time 23 : 59 : 40

Date 15 Jan 15

F/W WSi-400V-6B-V5

Serial no.
20315150589-1120-P001

Model no.
VP24C13/12C19
-63A-WSi/CR_EN/3B-1

M

◀ Outlet ▶

B1

◀ 01 ▶

Amp 10.9


kW 1.23

B1B3B5
B2B4B6

Page no.6
Touch °C / °F
to change
temp. unit


Page no.8
Wi / WSi outlet
measurement
PDU only

Phase Reading (400V, 63A, Bank x 6)




< 1.3 > Meter Reading & Setting


Setting < Three Phase PDU >



Monitored PDU




Switched PDU




PDU Level Setting

Default no. : 16



Buzzer ON / OFF

Default : ON




Default : Screen < ON > Scan < OFF >

* OFF Screen :

- Screen OFF in 30 seconds
- If want to turn on the screen just touch it
- OFF in 30 seconds if no any further touch

* ON Scan :


- Scanning starts in 30 seconds
- Then scan each page per 3 seconds



Outlet ON / OFF




Default : ON

WS / WSi Switched PDU only




Touchscreen Calibration

If no any calibrate touch in 30 seconds, it will return to Touchscreen page




< 1.4 > Meter (PDU) Cascade

- The PDU can be cascaded up to 16 levels
- For IP PDU access simply connect 1 x IP Dongle - IPD-04-S
- 1 x IP Dongle allows access to 16 levels
- Single & 3 Phase PDU can be inter-cascaded in the single daisy chain



To setup page for **PDU level setting** as below :



PDU Daisy Chain Terminator

To stabilize the data transmission among cascaded PDUs, it is a **MUST** to plug the terminator into the OUT port of **the last PDU meter.**



< 1.5 > IP Dongle Installation

IP Dongle Access to 16 PDU Levels

Patented IP Dongle provides IP remote access to the PDUs by a true network IP address chain. Only 1 x IP Dongle allows access to max. 16 PDUs in a single daisy chain - which is a highly efficient application for saving not only the IP remote accessories cost, but also the true IP addresses required on the PDU management.

Hot-Pluggable design facilitates the IP Dongle installation. Simply integrate the IP Dongle to the 1st PDU, then the entire daisy chain group can be remote over IP.




IP Dongle for vertical PDU

- SNMP function
- Free bundle a Daisy Chain Terminator



Installation steps :

- slide and fix the IP Dongle on the plate over the meter
- plug its RJ-45 connector into the LINK port of the **1st level PDU** meter
- plug the bundled daisy chain terminator into the OUT port of the **last level PDU** meter
- connect IP Dongle to network device via CAT. 5 / 6 cable



< 1.5 > IP Dongle Installation



Part no.
IPD-H04-S


IP Dongle for rackmount PDU

- SNMP function
- Free bundle a Daisy Chain Terminator



Installation steps :

- fix the IP Dongle on the rear side of rackmount PDU with 4 screws
- plug its RJ-45 connector into the LINK port of the 1st level PDU meter
- plug the bundled daisy chain terminator into the OUT port of the last level PDU meter
- connect IP Dongle to network device via CAT. 5 / 6 cable



< 1.6 > Meter System Timer

Each PDU comes with a system timer to show the current date & time.

It will be synchronized with the system time of the management PC under circumstances below:

- When the PDU connected to IPM-04 at the first time
- When the PDU is reconnected to IPM-04 after disconnection
- At 00:00:00 (hh:mm:ss) daily



The system timer will be frozen when the PDU is powered OFF.

< 1.7 > Optional Accessory

Temp. / Temp. + Humidity Sensor

W Meter provides 2 sensor ports for Temp. & Humidity monitoring. Once sensors connected, the reading will display in the meter.

- Plug n Play
- sensor with 2M or 4M cord
- low profile design with magnetic base for easy affixing to the cabinet



Temp. & Humid. Sensor

Part no. :

IG - TH01 - 2M (2M cord)

IG - TH01 - 4M (4M cord)




Temp. Sensor

Part no. :

IG - T01 - 2M (2M cord)

IG - T01 - 4M (4M cord)



< 1.7 > Optional Accessory

Temp. / Temp. + Humidity Sensor



		Temp. & Humid. Sensor	Temp. Sensor
Part no.		IG - TH01	IG - T01

Temperature Sensitivity	Range	0 to 80°C (32 to 176°F)	
	Accuracy	±1.0°C typical (±2°F)	±1.5°C (±3°F)
	Resolution	0.1°C (0.2°F)	
	Response Time	5 to 30 sec	

Relative Humidity Sensitivity	Range	0 to 100% R.H	/
	Accuracy	0 to 100, ±8.0% R.H 20 to 80, ±4.5% R.H.	/
	Resolution	1% R.H.	/
	Response Time	8 sec	/

Power Requirement	Voltage	12VDC, powered by sensor port	
	Current Consumption	20mA	
	Power consumption	0.24 Watt	
	Power on indicator	Red LED	Green LED

Housing	Chassis & Cover	plastic	
	Color	Dark gray	
	Installation	Magnetic base for unrestricted installation	

Cable	Cable Length	TH sensor w/ 2m cable (standard) TH sensor w/ 4m cable (option)	T sensor w/ 2m cable (standard) T sensor w/ 4m cable (option)
	Cable Specification	4-wired 3.5mm to RJ11	
	Cable Color	Black	Beige

Environmental	Operating	0 to 80°C Degree	
	Storage	-5 to 80°C Degree	
	Humidity	0~100%, non-condensing	

Dimensions	Product	30L x 25Wx 18H mm	
------------	---------	-------------------	--

Weight	Net	10g	
--------	-----	-----	--

Compatibility	InfraPower	Single & 3 Phase W / WS / Wi / WSi series PDU	
	InfraSolution	X-2000 series	
	InfraGuard	Cabinet sensor system	

Safety Regulatory	FCC & CE certified		
-------------------	--------------------	--	--


Environmental	RoHS2 & REACH compliant		
---------------	-------------------------	--	--

< 1.7 > Optional Accessory

Extended Door-mount Amp / Temp. Display

External Door Mount PDU Display (IP-ED-02) provides RJ-11 port x 2 for PDU amp. & Temperature monitoring. Once connected, the reading of PDU amp. and the temp. shows in the external door mount display.


- Plug n Play
- Support two PDUs display amp. and temp.
- Adjustable Mounting Kit for easy installation to cabinet door
- Bundled 3m RJ-11 cable x 2



Package Contents

- Extended Door-mount Amp. / Temp. Display x 1
- Bundled 3m RJ-11 cable x 2
- Screw & tape not provided

Product Dimension



Packing Dimension

- 350(W) x 165(L) x 35(H) mm

Weight


- Net : 0.24kg
- Gross : 0.47kg

< 1.7 > Optional Accessory

Extended Door-mount Amp / Temp. Display

Installation steps :

- connect the meter and extended door-mount PDU display via a bundled RJ-11 cable
- only meter TH2 port supports the door-mount PDU display
- the display on the door top corner position is recommended
- fix the display on the cabinet door by screw or tape



Part II. Software

< 2.1 > Key Features

InfraPower Manger IPM-04 is a free but powerful and user friendly PDU mangement software. The Windows based software consolidates management of max. 800 single & three phase PDUs via 50 IP dongles.

5 concurrent user access are bundled for achieving the demand of multi-user / multi-tasking in nowadays' time-sharing data center operation.


InfraPower IPM-04


Features		
Capacity	IP Dongle Group (Just 1 for 16 PDU levels)	50
	PDU number	800
	Concurrent Users	5
Enhanced Features	Outlet Level kWh & Amp Measurement	✓
	Outlet Scheduling	✓
	Energy Consumption (kWh) Monitoring	✓
	Apparent Power (kVA) Monitoring	✓
	Power Factor Measurement	✓
	Circuit Breaker Monitoring	✓
	SNMP Capability via IP Dongle	✓
Basic Features	Aggregate Current (Amp) Monitoring	✓
	Individual Outlet Switch ON/OFF	✓
	Temp-Humid Monitoring	✓
	Alarm Threshold Setting	✓
	Rising Alert Threshold Setting	✓
	Remote Access via Web	✓
	Graphic User Interface	✓
	Reporting	✓
PDU Series Support	Single & 3 Phase W Monitored PDU	✓
	Single & 3 Phase Wi Monitored PDU (Outlet Measurement)	✓
	Single & 3 Phase WS Switched PDU	✓
	Single & 3 Phase WSi Switched PDU (Outlet Measurement)	✓


< 2.2 > IP Dongle Configuration

After the completion of IP Dongle connection, please take the following steps to configure the IP Dongle :


- Step 1.** Prepare a notebook computer to download the IP setup utilities from the link :
<http://www.austin-hughes.com/support/utilities/infrapower/IPdongleSetup.msi>
- Step 2.** Double Click the IPDongleSetup.msi and follow the instruction to complete the installation
- Step 3.** Go to each first level PDU with the notebook computer & a piece of CAT. 5 / 6 cable to configure the IP Dongle by IP setup utilities as below. Please take the procedure for all IP dongles **ONE BY ONE**



 Reconnect the IP Dongle with the network device (router or hub), after finish IP Dongle configuration.

 Ensure the PDU in power ON status

The screenshot shows the 'IP setup utilities for IP Dongle (Ver. Q411Y1)' window. The 'Configuration' tab is active, showing fields for Name, Location, Password, New password, Confirm new password, IP address, Subnet mask, and Gateway. The 'Save' button is circled in red.

 Write down the new IP address & password for < Setup > purpose, refer to < 3.1 > System Setup

- Step 4.** Click “ **Scan** ” to search the connected IP Dongle
- Step 5.** Enter device name in “ **Name** ” (min. 4 char. / max. 16 char.). Default is “ **Name** ”
- Step 6.** Enter device location in “ **Location** ” (min. 4 char. / max. 16 char.). Default is “ **Rack_001** ”
- Step 7.** Enter password in “ **Password** ” for authentication (min. 8 char. / max. 16 char.) Default is “ **00000000** ”
- Step 8.** Enter new password in “ **New password** ” (min. 8 char. / max. 16 char.)
- Step 9.** Re-enter new password in “ **Confirm new password** ”
- Step 10.** Input the desired “ **IP address** ” / “ **Subnet mask** ” / “ **Gateway** ”, then Click “ **Save** ” to confirm the input

The default IP setting is as below : IP address : 192.168.0.1
Subnet mask : 255.255.255.0
Gateway : 192.168.0.254

< 2.3 > Hardware Requirements of the Management PC

Please prepare a management PC with the hardware requirements as below for InfraPower Manager - IPM-04

Recommended hardware requirements :

- Processor: Dual Core 2GHz or above
- Memory: 2GB RAM
- Available Disk Space: 500GB
- Drive: DVD ROM drive
- Display: 1440 x 900 or higher resolution monitor
(for the best view, resolution is 1920 x 1080)



- The default service port of web server is 80.
- A dedicated PC to run InfraPower Manager - IPM-04 is recommended.
- Make sure the management PC is POWER ON & IPM-04 is under operation.
Otherwise, daily data backup will NOT be proceeded.

< 2.4 > Supported OS Platform & Language

InfraPower Manager – IPM-04 supports the OS platforms & languages as below:


- MS Windows XP Professional with SP3 (32bit only)
- MS Windows 7 Professional with SP1
- MS Windows Server 2003 R2 Standard Edition with SP2
- MS Windows Server 2008 Standard Edition SP2
- MS Windows Server 2008 R2 Standard Edition SP1



Ensure the user logs in the management PC as a member of “Administrators” Group before IPM-04 Installation and execution.

User can select the following languages under Control Panel > Region and Language in English Edition OS:

- 1) Arabic (Saudi Arabia)
- 2) Chinese (Traditional, Hong Kong S.A.R.)
- 3) Dutch (Netherlands)
- 4) English (Australia)
- 5) English (United Kingdom)
- 6) English (United States)
- 7) French (France)
- 8) German (Germany)
- 9) German (Switzerland)
- 10) Italian (Italy)
- 11) Japanese (Japan)
- 12) Korean (Korea)
- 13) Norwegian (Norway)
- 14) Portuguese (Portugal)
- 15) Russian (Russia)
- 16) Spanish (Spain)
- 17) Turkish (Turkey)



< 2.5 > Software Download

InfraPower Manager, IPM-04, is a **PDU** management software to enhance the features and benefits of all W series Single & 3 Phase PDUs by providing a centralized and remote management platform, and total reporting with detailed logs & event occurrences.

IPM-04 supports max. 5 concurrent login users and manage multi- IP Dongle groups max. 50, hence the concurrent login users can access & remote PDUs max. 800 (50 IP dongles x 16 level PDUs).

Software download

Please download the InfraPower Manager - IPM-04 to the management PC
from the link <http://www.austin-hughes.com/support/software/infrapower/IPM-04.msi>

Double click the IPM-04.msi and follow the instruction to complete the installation.



↓
click “ **Next** ”

↓
click “ **Install** ”

↓
click “ **Finish** ”



..... **Complete**



< 2.6 > First Time Start-up Setting

Step 1. Double Click the **InfraPower Manager - IPM-04**
and follow the instruction to complete start-up setting.



For MS Windows 7 and MS Windows server 2008,
it requires to run a program with administrator rights before execution:

- Right click **InfraPower Manager - IPM-04** , and then select **Properties**.
- Click the **Compatibility** tab.
- Tick the box **Run this program as an administrator**, and then click OK.



< 2.6 > First Time Start-up Setting

Step 2. Click “ **Next** ” in “ **InfraPower Manager start-up setting** ” box

Step 3. Input the fields of the following window & Click “ **Install** ”

Software component(s) analysis & installation

The following 3 software component(s) are required to run InfraPower Manager .

(1) Apache 2.2 Please decide to use the existing or new Apache 2.2.

☐ Use existing Apache
(Tick this if the management PC has been already installed Apache)

☒ Install new Apache 2.2

Folder :

Port :

(2) PHP 5 Please decide to use the existing or new PHP 5.

☐ Use existing PHP
(Tick this if the management PC has been already installed PHP)

☒ Install new PHP 5

Folder :

(3) PostgreSQL 9.0 Please decide to use the existing or new PostgreSQL 9.0.

☐ Use existing PostgreSQL
(Tick this if the management PC has been already installed PostgreSQL)


☒ Install new PostgreSQL 9.0

Folder :

PostgreSQL login :

PostgreSQL password :

--If the port of web server is not 80, please input the appropriate no. here and follow the instruction in “ Change port no. of web server” next page to make the change effective.

-  PostgreSQL password can be changed by user.
The password **MUST** contain at least three of the following four character groups:
- English uppercase characters (A through Z)
 - English lowercase characters (a through z)
 - Numerals (0 through 9)
 - Non-alphabetic characters (such as !, \$, #, %)

..... • **Complete**

< 2.7 > Web Server Port no. Change

Web server port no. change


If users want to use another port no. instead of 80, please take the following steps after

InfraPower Manager IPM-04 “ **First time start-up setting** ” is completed.

Step 1. Go to the path of web server being installed. (Default: C:\AppServ\Apache2.2\conf\)

Step 2. Open “ **httpd.conf** ” & change “ **Listen 80** ” to “ **Listen xx** ” where xx means that the port no. will be selected by the user

Step 3. Save the change of “ **httpd.conf** ”



The screenshot shows a text editor window with the file 'httpd.conf' open. The text is as follows:

```
58 #  
59 # Listen: Allows you to bind Apache to specific IP addresses and/or  
60 # ports, instead of the default. See also the <VirtualHost>  
61 # directive.  
62 #  
63 # Change this to Listen on specific IP addresses as shown below to  
64 # prevent Apache from glomming onto all bound IP addresses (0.0.0.0)  
65 #  
66 #Listen 12.34.56.78:80  
67 Listen 80  
68 #  
69 #  
70 # This configuration file reflects default settings for Apache HTTP Server.  
71 #  
72 # You may change these, but chances are that you may not need to.  
73 #  
74 #  
75 #  
76 # Timeout: The number of seconds before receives and sends time out.  
77 #  
78 Timeout 300  
79
```

The line 'Listen 80' on line 67 is circled in red.

Step 4. Restart Apache services.

Go to Control Panel > Administrative Tools > Services > Apache2.2 & Click “ **Restart** ”

..... **Complete**


Part III. System Setup & Remote Access

< 3.1 > System Setup

Users can follow below step 1 - 3 to access the management PC and InfraPower Manager IPM-04

Step 1. Open Internet Explorer (I.E.), version 8.0 or above


Step 2. Enter the URL of management PC into the address bar

 (If fail to access, please ask MIS to check if the port for web server is enable.
Default port : 80)

e.g. <http://192.168.0.1/IPM-04/>

Step 3. Enter “ **User name** “. Default is “ **admin** “


Enter “ **Password** “. Default is “ **00000000** “



System authentication

User name

Password



Only one administrator among 5 concurrent users

Only Administrator is authorised to access < **User** >, < **Setup** >, < **Alarm** >, < **General** > & < **Backup** >

< 3.1 > System Setup

In < **User** >, administrator can create 4 more operators (concurrent users).

Step 1. Tick “ **Operator 1:** “

Step 2. Input “ **User name** “ & “ **User login password** “

Step 3. Input user login password in “ **Confirm password** “ again

Step 4. Repeat Step 1 to 3 for other operators

Step 5. Click “ **Apply** “ to finish the user setup

User setup

	Activate	User name	User login password	Confirm password
Administrator :	<input checked="" type="checkbox"/>	<input type="text" value="admin"/>	<input type="password" value="....."/>	<input type="password" value="....."/>
<ul style="list-style-type: none">• Only administrator is authorised to access SYSTEM SETTING.• Only administrator is authorised to set and change all users' password.• Min. 4 char. and max. 16 char. for user name.• Min. 8 char. and max. 16 char. for user login password.• If there is any change of user name, system will automatically delete the original operator and create a new one. A new user login password is required.				
Operator 01 :	<input checked="" type="checkbox"/>	<input type="text" value="Kenny.Wong"/>	<input type="password" value="....."/>	<input type="password" value="....."/>
Operator 02 :	<input checked="" type="checkbox"/>	<input type="text" value="William.Wong"/>	<input type="password" value="....."/>	<input type="password" value="....."/>
Operator 03 :	<input type="checkbox"/>	<input type="text"/>	<input type="password"/>	<input type="password"/>
Operator 04 :	<input type="checkbox"/>	<input type="text"/>	<input type="password"/>	<input type="password"/>
<div><input type="button" value="Apply"/> <input type="button" value="Cancel"/></div>				

< 3.1 > System Setup

In < **Setup** >, administrator can activate max. 50 IP Dongle groups & set the group command password

Step 1. “ **Activate** ” IP Dongle group 01

Step 2. Input “ **IP address** ” & “ **password** ” of the IP Dongle

Step 3. “ **Enable** ” Command password

Step 4. Input “ **New command password** ”. Default is “ **00000000** ”

Step 5. Input new command password in “ **Confirm new password** ” again.

Step 6. Click “ **Apply** ” to finish the IP Dongle group setup

Step 7. Repeat step 1 to 6 for other IP Dongle groups

*** Initially, please setup the IP dongle one by one.**

IP dongle group 01 : ☒ **Activate** ☐ **Deactivate**

- DO NOT activate the group if there is no any IP dongle and PDU connection.
- Each IP dongle group consist of one IP dongle and max. 16 PDU.

01 IP dongle setting

IP dongle address :

IP dongle password :

- If the administrator wants to change IP dongle address and password, two steps are required.
- **Firstly**, enter the IP Setup utilities to make the change. (ref. to User Manual < IP Dongle Configuration >)
- **Secondly**, return to this page to make the same change on IP address and password.

01 IP dongle group

Command password : ☐ **Enable** ☒ **Disable**

New command password :

Confirm new password :

- Administrator needs to set command password for IP dongle groups one by one.
- Command password required for any PDU configuration and control.
- Administrator can set different command password for different IP dongle group or all IP dongle groups share the same password.

< 3.1 > System Setup

In < **Alarm** >, administrator can configure the alarm email server & max. 5 email recipients to receive alarm notifications from the software

Default is “**Disable**”.

Step 1. “ **Enable** “ alarm email

Step 2. Input “ **SMTP server** ” and “ **SMTP port** “

Step 3. Input “ **User email** “

Step 4. “ **Enable** “ or “ **Disable** “ the “ **SMTP authentication** “

Step 5. Input “ **User name** “ and “ **Password** “

Step 6. Select the “ **SMTP secure** “ (None / SSL / TLS)

Step 7. Input the “ **Alarm interval** “

Step 8. Input the alarm recipient email account in “ **Alarm mail recipient 01** “

Step 9. Repeat step 8 for other alarm recipients

Step 10. Click “ **Apply** “ to finish the alarm email server setting

Alarm email server setting

Alarm email :

☒ Enable ☐ Disable

SMTP server :

SMTP port :

User email :

SMTP authentication :

☒ Enable ☐ Disable

User name :

Password :

SMTP secure :

▼

Alarm interval :

(Min. 10, Max. 60 minutes)

• This alarm setting is for all IP dongle PDU groups.

Alarm email to

Alarm mail recipient 01 :

×

Alarm mail recipient 02 :

Alarm mail recipient 03 :

Alarm mail recipient 04 :

Alarm mail recipient 05 :

Apply

Cancel

< 3.1 > System Setup

In < **General** >, administrator can change the “ **Refresh rate** “ , “ **Scan rate** “ & “ **Temperature unit** “ across all IP Dongle groups

Auto data refresh
Refresh rate : (Min. 10, Max. 60 seconds)

- Auto data refresh rate on the page of **PDU STATUS**, **PDU DETAILS**, **OUTLET SCHEDULE OVERVIEW** and **TH STATUS**.

IP dongle groups auto scan
Scan rate : (Min. 5, Max. 60 seconds)

- Auto scan rate on the page of **PDU STATUS**, **OUTLET SCHEDULE OVERVIEW** and **TH STATUS**.

Temperature unit
Unit : ☒ °C ☐ °F

In < **Backup** >

Default is “ **Enable** “

Default Backup Path : “ **C:\Program Files\InfraPower Manager (IPM-04)** “

Data backup setting
Daily backup : ☒ Enable ☐ Disable
Backup to :
Example : C:\Program Files\IPM-04\

- Daily backup proceeded at 00:00 for last 24 hours data.
- The backup data for **THREE PHASE LOG**, **SINGLE PHASE LOG**, **63A LOG**, **TH SENSOR LOG**, **EVENT** saved in CSV file format.
- Folder will be automatically created under the path you entered.

< 3.2 > Remote Access

After the completion of < **System Setup** > administrator and 4 concurrent users can access the management PC remotely. All of them can follow the steps below to access management PC &

IPM-04

Step 1. Add the port of web server in the firewall settings of the management PC.

- Open “ **Control Panel** ”
- Select “ **Windows Firewall** ”
- Select “ **Advanced settings** ”
- Right Click “ **Inbound Rules** ” & select “ **New Rule...** ”
- Select “ **Port** ” & Click “ **Next>** ”
- Select “ **TCP** ” then “ **All local ports** ” & Click “ **Next>** ”
- Select “ **Allow the connection** ” & Click “ **Next>** ”
- Tick all three options & Click “ **Next>** ”
- Input the “ **Name** ” & “ **Description** ” of the port & Click “ **Finish** ”

Step 2. Open the web browser of remote client PC

Step 3. Input the URL of InfraPower Manager IPM-04 in the address bar

e.g. <http://192.168.0.1/IPM-04/>



If the port no. of web server is not 80, please enter the appropriate port no. follow the IP address e.g. <http://192.168.0.1:81/IPM-04/>

Step 4. System authentication page pops up automatically.

Input “ **User name** ”, “ **Password** ” & Click “ **Login** ”

System authentication

User name

Password

< 4.2 > Details

In < Details > ,

- Change “ **Name** ” and “ **Location** ” of PDU & Click “ **Apply** ”
- Change “ **Alarm amp.** ” . “ **Rising alert amp.** ” & “ **Low alert amp.** ” of PDU’s banks or circuits & Click “ **Apply** ”
- Click “ **Reset** ” to reset peak amp. and kWh of PDU’s banks or circuits if necessary
- Click “ **ON / OFF** ” to switch ON / OFF outlet (Switched PDU only)
- View On / OFF status of each PDU’s outlet
- View aggregated current on the PDU
- View latest loading & energy consumption of each PDU outlet (Outlet Measurement PDU only)
- View latest Voltage of each PDU bank or circuit

PDU details

Level : VP24C13/6C19-32A-W Name : kWh : 0.00 Power factor : 0.00
Status : Connected Location : Load amp : 0.0 kVA : 0.00

Bank	Voltage	Max. amp	Alarm amp	Rising alert amp	Low alert amp	Peak amp	kWh	Reset
L1 - B1	211.7	16	13.0	0.0	0.0	0.0	0.00	<input type="button" value="Reset"/>
L1 - B2	211.7	16	13.0	0.0	0.0	0.0	0.00	<input type="button" value="Reset"/>
L2 - B3	216.8	16	13.0	0.0	0.0	0.0	0.00	<input type="button" value="Reset"/>
L2 - B4	216.8	16	13.0	0.0	0.0	0.0	0.00	<input type="button" value="Reset"/>
L3 - B5	216.0	16	13.0	0.0	0.0	0.0	0.00	<input type="button" value="Reset"/>
L3 - B6	216.0	16	13.0	0.0	0.0	0.0	0.00	<input type="button" value="Reset"/>

Outlet	Name	Amp	kWh	kVA	Status	Switch
01	outlet_name_01	-	-	-	ON	<input type="button" value="OFF"/>
03	outlet_name_03	-	-	-	ON	<input type="button" value="OFF"/>
05	outlet_name_05	-	-	-	ON	<input type="button" value="OFF"/>
07	outlet_name_07	-	-	-	ON	<input type="button" value="OFF"/>
C01	outlet_name_09	-	-	-	ON	<input type="button" value="OFF"/>
02	outlet_name_02	-	-	-	ON	<input type="button" value="OFF"/>
04	outlet_name_04	-	-	-	ON	<input type="button" value="OFF"/>
06	outlet_name_06	-	-	-	ON	<input type="button" value="OFF"/>
08	outlet_name_08	-	-	-	ON	<input type="button" value="OFF"/>
C02	outlet_name_10	-	-	-	ON	<input type="button" value="OFF"/>
01	outlet_name_11	-	-	-	ON	<input type="button" value="OFF"/>
03	outlet_name_13	-	-	-	ON	<input type="button" value="OFF"/>
05	outlet_name_15	-	-	-	ON	<input type="button" value="OFF"/>
07	outlet_name_17	-	-	-	ON	<input type="button" value="OFF"/>
C01	outlet_name_19	-	-	-	ON	<input type="button" value="OFF"/>
02	outlet_name_12	-	-	-	ON	<input type="button" value="OFF"/>
04	outlet_name_14	-	-	-	ON	<input type="button" value="OFF"/>
06	outlet_name_16	-	-	-	ON	<input type="button" value="OFF"/>
08	outlet_name_18	-	-	-	ON	<input type="button" value="OFF"/>
C02	outlet_name_20	-	-	-	ON	<input type="button" value="OFF"/>
01	outlet_name_21	-	-	-	ON	<input type="button" value="OFF"/>
03	outlet_name_23	-	-	-	ON	<input type="button" value="OFF"/>
05	outlet_name_25	-	-	-	ON	<input type="button" value="OFF"/>
07	outlet_name_27	-	-	-	ON	<input type="button" value="OFF"/>
C01	outlet_name_29	-	-	-	ON	<input type="button" value="OFF"/>
02	outlet_name_22	-	-	-	ON	<input type="button" value="OFF"/>
04	outlet_name_24	-	-	-	ON	<input type="button" value="OFF"/>
06	outlet_name_26	-	-	-	ON	<input type="button" value="OFF"/>
08	outlet_name_28	-	-	-	ON	<input type="button" value="OFF"/>
C02	outlet_name_30	-	-	-	ON	<input type="button" value="OFF"/>


Click outlet icon for setting

☐ Auto data refresh : ☐ Unlick during data input All IPM communication to and from the PDU is stopped, notification to the user is stopped, and the PDU readings are "-".
 Save new data
 Cancel new data input
* Press F11 to enlarge or diminish the screen

< 4.3 > Outlet Setting

In < **Outlet setting** > ,

- Change PDU's outlet name
- Change “ **Power up sequence delay** ” of PDU's outlet (Switched PDU only)
- Change “ **Alarm amp.** ” , “ **Rising alert amp.** ” & “ **Low alert amp.** ” of PDU's outlet
(Outlet Measurement PDU only)

-  Click “ **Apply** ” to finish the above settings
- Click “ **Reset** ” to reset peak amp. or kWh of PDU's outlet (Outlet Measurement PDU only)

Outlet setting


PDU level : VF24C13/6C19-32A-W

Status : Connected

Name : 3PW30-32A

Location : Rack_006

L1 - B1

Outlet : 

Name :

Status : ON

Apply

Save new data

Cancel

Cancel new data input

Exit

Return to PDU DETAILS

< 4.4 > **Sensor Status**

In < **TH status** > ,

- View status, location, latest reading & alarm setting of Temp. & Humid sensors

 The GUI will not show the readings if the TH sensors are **NOT** installed & activated.

Sensor status

IP dongle name : default_ipd_name

IP address : 192.168.1.80

PDU				TH 1				TH 2				
Level	Name	Setting	Location	°C			%	Location	°C			%
				Temp.	Alarm	R. alert	Humid./ Alarm / R. alert		Temp.	Alarm	R. alert	Humid./ Alarm / R. alert
01	W18-16A		Front_Top	22.4	/	35.0	/ 0.0	40.7 / 65.0 / 0.0	Rear_Top	21.6	/ 35.0 / 0.0	43.4 / 65.0 / 0.0
02	WS24-32A		-	-	/	-	/ -	- / - / -	-	-	/	- / -
03	W24-32A		-	-	/	-	/ -	- / - / -	-	-	/	- / -
04	W44-63A		-	-	/	-	/ -	- / - / -	-	-	/	- / -
05	3P18W-32A		-	-	/	-	/ -	- / - / -	-	-	/	- / -
06	3PW30-32A		-	-	/	-	/ -	- / - / -	-	-	/	- / -
07	3PW30-32A		-	-	/	-	/ -	- / - / -	-	-	/	- / -
08	3PW30-32A		-	-	/	-	/ -	- / - / -	-	-	/	- / -
09	default_pdu_name		Disconnected	-	/	-	/ -	- / - / -	Disconnected	-	/	- / -
10	default_pdu_name		Disconnected	-	/	-	/ -	- / - / -	Disconnected	-	/	- / -
11	default_pdu_name		Disconnected	-	/	-	/ -	- / - / -	Disconnected	-	/	- / -
12	default_pdu_name		Disconnected	-	/	-	/ -	- / - / -	Disconnected	-	/	- / -
13	default_pdu_name		Disconnected	-	/	-	/ -	- / - / -	Disconnected	-	/	- / -
14	default_pdu_name		Disconnected	-	/	-	/ -	- / - / -	Disconnected	-	/	- / -
15	default_pdu_name		Disconnected	-	/	-	/ -	- / - / -	Disconnected	-	/	- / -
16	default_pdu_name		-	-	/	-	/ -	- / - / -	-	-	/	- / -

☒ Auto data refresh : Untick during data input

Search

Search new Installed PDUs

* Press F11 to enlarge or diminish the screen

< 4.5 > Sensor Setting

In < TH setting > ,

- Default TH setting :
- “ **Activate** ” Temp. & Humid sensors ONLY when they are connected
- Change “ **Location** ” , “ **Rising alert Setting** ” & “ **Alarm Setting** ” of Temp. & Humid sensors
- Click “ **Apply** ” to finish the above settings



If no any TH sensor connected, NEVER activate.

Sensor setting

PDU level : V12C13/6C19-16A-W
Status : Connected
Name : W18-16A
Location : Rack_001

TH 1
☒ Activate ☐ Deactivate
Location :

	Alarm	Rising alert	Reading
	Setting		
Temp. (°C) :	<input type="text" value="35.0"/>	<input type="text" value="0.0"/>	22.4
Humid. (%) :	<input type="text" value="65.0"/>	<input type="text" value="0.0"/>	40.6

TH 2
☒ Activate ☐ Deactivate
Location :

	Alarm	Rising alert	Reading
	Setting		
Temp. (°C) :	<input type="text" value="35.0"/>	<input type="text" value="0.0"/>	21.6
Humid. (%) :	<input type="text" value="65.0"/>	<input type="text" value="0.0"/>	43.0

- DO NOT activate T or TH sensor if no sensor installed.
- When install T or TH sensor, please tick activate. Otherwise, no readings display.

Save new data

Return to TH STATUS

Cancel new data input





< 4.6 > Outlet Schedule Overview

< **Outlet Schedule Overview** > provides an overview on outlet schedule setting of PDUs, and scan the page by IP Dongle group one by one.

Outlet schedule overview

IP dongle name : default_ipd_name
IP address : 192.168.0.1

Page : 1

PDU		Setting	Outlet Schedule # 1 - 2		Outlet Schedule # 3 - 4		Outlet Schedule # 5 - 6	
Level	Name		Name	Action	Name	Action	Name	Action
01	default_pdu_name		ScheduleName_01	Daily - On	-	Disabled	-	Disabled
			-	Disabled	-	Disabled	-	Disabled
02	default_pdu_name		-	Disabled	-	Disabled	-	Disabled
			-	Disabled	-	Disabled	-	Disabled
03	default_pdu_name		-	Disabled	-	Disabled	-	Disabled
			-	Disabled	-	Disabled	-	Disabled
04	default_pdu_name		-	Disabled	-	Disabled	-	Disabled
			-	Disabled	-	Disabled	-	Disabled

☒ Auto data refresh : Untick during data input

Search

Search new installed PDUs

* Press F11 to enlarge or diminish the screen

< 4.7 > Outlet Schedule Setting

In < **Outlet Schedule Setting** >, user can set max. 6 outlet On / Off schedules in each PDU.

The outlet schedule can be set on one-time, daily or weekly basis. (Switched PDU only)

Outlet schedule setting

PDU level: VP24C13/6C19-32A-W

Status: Connected

Name: default_pdu_name

Location: default_pdu_loc.

Outlet schedule: ☐ Disable ☒ Enable

Name:

Action: ☐ OFF ☒ ON

Time: ☒ Daily ☐ Weekly ☐ One-Time


: (24 hours format)

Outlet schedule


PDU

L1 - B1


☒

01  outlet_name_01


☒

03  outlet_name_03


☐

05  outlet_name_05

☐


07  outlet_name_07

☐


C01  outlet_name_09

L1 - B2


☐

02  outlet_name_02


☐

04  outlet_name_04


☐

06  outlet_name_06

☐


08  outlet_name_08

☐


C02  outlet_name_10

L2 - B3


☐

01  outlet_name_11


☐

03  outlet_name_13


☐

05  outlet_name_15

☐

07  outlet_name_17

☐

C01  outlet_name_19

☐

02  outlet_name_12

☐

04  outlet_name_14

☐

06  outlet_name_16

☐

08  outlet_name_18

☐

C02  outlet_name_20

☐

01  outlet_name_21

☐

03  outlet_name_23

☐

05  outlet_name_25

☐

07  outlet_name_27

☐

C01  outlet_name_29

☐

02  outlet_name_22

☐

04  outlet_name_24

☐

06  outlet_name_26

☐

08  outlet_name_28

☐

C02  outlet_name_30

Apply

Save new data

Cancel

Cancel new data input

Exit

Return to OUTLET SCHEDULE

< 4.7 > Outlet Schedule Setting

PDU outlet schedule is a function allowing users to set a specific time to switch either ON or OFF the outlets on daily, weekly or one-time basis.





Each PDU provides **6 schedule tasks**. Users can follow the steps below to enable the PDU outlet schedule

Step 1. Go to < **Outlet Schedule Overview** > page, Click “ **Setting** ”

Outlet schedule overview

IP dongle name : default_ipd_name
IP address : 192.168.0.1

Page : 1

PDU Level	Name	Setting	Outlet Schedule # 1 - 2		Outlet Schedule # 3 - 4		Outlet Schedule # 5 - 6	
			Name	Action	Name	Action	Name	Action
01	default_pdu_name		ScheduleName_01	Daily - On	-	Disabled	-	Disabled
			-	Disabled	-	Disabled	-	Disabled
02	default_pdu_name		-	Disabled	-	Disabled	-	Disabled
			-	Disabled	-	Disabled	-	Disabled
03	default_pdu_name		-	Disabled	-	Disabled	-	Disabled
			-	Disabled	-	Disabled	-	Disabled
04	default_pdu_name		-	Disabled	-	Disabled	-	Disabled
			-	Disabled	-	Disabled	-	Disabled

☒ Auto data refresh : Untick during data input

Search

Search new installed PDUs

* Press F11 to enlarge or diminish the screen

< 4.7 > Outlet Schedule Setting

Step 2. In < **Outlet Schedule Setting** > page, Select “ **Outlet schedule 1** ” & Tick “ **Enable** ”

Step 3. Provide the name of the outlet schedule

Step 4. Select the action (either ON or OFF)

Step 5. Select the time for outlet schedule.

Outlet schedule : 1 ☐ Disable ☒ Enable
Name : OutletSchedule01
Action : ☒ OFF ☐ ON
Time : ☒ Daily ☐ Weekly ☐ One-Time
00 : 00 (24 hours format)

Daily ON / OFF Schedule

Outlet schedule : 1 ☐ Disable ☒ Enable
Name : OutletSchedule01
Action : ☒ OFF ☐ ON
Time : ☐ Daily ☒ Weekly ☐ One-Time
Sun
00 : 00 (24 hours format)

Weekly ON / OFF Schedule

Outlet schedule : 1 ☐ Disable ☒ Enable
Name : OutletSchedule01
Action : ☒ OFF ☐ ON
Time : ☐ Daily ☐ Weekly ☒ One-Time
01 / 01 (MM / DD date format)
00 : 00 (24 hours format)

One-time ON / OFF Schedule

< 4.7 > Outlet Schedule Setting

Step 6. Tick the outlets to switch ON / OFF

The screenshot shows the 'Outlet schedule' window with a list of outlets grouped by phase and bus. The outlets are listed as follows:

- PDU**
- L1 - B1**
 - ☒ 01 outlet_name_01
 - ☒ 03 outlet_name_03
 - ☐ 05 outlet_name_05
 - ☐ 07 outlet_name_07
 - ☐ C01 outlet_name_09
- L1 - B2**
 - ☐ 02 outlet_name_02
 - ☐ 04 outlet_name_04
 - ☐ 06 outlet_name_06
 - ☐ 08 outlet_name_08
 - ☐ C02 outlet_name_10
- L2 - B3**
 - ☐ 01 outlet_name_11
 - ☐ 03 outlet_name_13
 - ☐ 05 outlet_name_15
 - ☐ 07 outlet_name_17
 - ☐ C01 outlet_name_19
- L2 - B4**
 - ☐ 02 outlet_name_12
 - ☐ 04 outlet_name_14
 - ☐ 06 outlet_name_16
 - ☐ 08 outlet_name_18
 - ☐ C02 outlet_name_20
- L3 - B5**
 - ☐ 01 outlet_name_21
 - ☐ 03 outlet_name_23
 - ☐ 05 outlet_name_25
 - ☐ 07 outlet_name_27
 - ☐ C01 outlet_name_29
- L3 - B6**
 - ☐ 02 outlet_name_22
 - ☐ 04 outlet_name_24
 - ☐ 06 outlet_name_26
 - ☐ 08 outlet_name_28
 - ☐ C02 outlet_name_30

At the bottom of the window, there are four buttons: 'Apply' (circled in red), 'Save new data', 'Exit', and 'Return to OUTLET SCHEDULE'. Below the 'Apply' button is a 'Cancel' button with the text 'Cancel new data input'.

Step 7. Click “ **Apply** ” to save the settings

Step 8. Repeat step 2 to 7 for Outlet Schedule no.2 to 6 if necessary



If the outlet schedule task is “ **One-Time** “, the setting will return to “ **Disable** “ once the task is completed.

To cancel the outlet schedule, tick “ **Disable** “ & Click “ **Apply** “ to finish the change.

Part V. Log & Events

< 5.1 > Single Phase PDU / Outlet Log

< Single Phase PDU Log >

provides past 2000 log records of each Single Phase PDU.
The software will generate a PDU log record every 10 mins.

Single Phase PDU log

PDU level : 16

Date	Time	Model	Name	Location	Status	Circuit A			Circuit B			Total		
						Amp	kWh	kVA	Amp	kWh	kVA	Amp	kWh	kVA
						Max. / Load / Alarm / R. alert / L. alert			Max. / Load / Alarm / R. alert / L. alert			Load		
2014/09/25	16:35:18	V4UK/20C13-32A-WS	WS24-32A	Rack_001	Connected	16 / 0.0 / 5.0 / 3.0 / 0.0	0.00	0.00	16 / 0.2 / 5.0 / 3.0 / 0.0	0.23	0.03	0.2	0.23	0.03
2014/09/25	16:25:17	V4UK/20C13-32A-WS	WS24-32A	Rack_001	Connected	16 / 0.0 / 5.0 / 3.0 / 0.0	0.00	0.00	16 / 0.0 / 5.0 / 3.0 / 0.0	0.23	0.04	0.0	0.23	0.05
2014/09/25	16:15:16	V4UK/20C13-32A-WS	WS24-32A	Rack_001	Connected	16 / 0.0 / 5.0 / 3.0 / 0.0	0.00	0.00	16 / 0.0 / 5.0 / 3.0 / 0.0	0.23	0.05	0.0	0.23	0.05
2014/09/25	16:05:15	V4UK/20C13-32A-WS	WS24-32A	Rack_001	Connected	16 / 0.0 / 5.0 / 3.0 / 0.0	0.00	0.00	16 / 0.0 / 5.0 / 3.0 / 0.0	0.23	0.02	0.0	0.23	0.02
2014/09/25	15:55:14	V4UK/20C13-32A-WS	WS24-32A	Rack_001	Connected	16 / 0.0 / 5.0 / 3.0 / 0.0	0.00	0.00	16 / 0.0 / 5.0 / 3.0 / 0.0	0.23	0.04	0.0	0.23	0.04
2014/09/25	15:45:13	V4UK/20C13-32A-WS	WS24-32A	Rack_001	Connected	16 / 0.0 / 5.0 / 3.0 / 0.0	0.00	0.00	16 / 0.1 / 5.0 / 3.0 / 0.0	0.23	0.03	0.1	0.23	0.03
2014/09/25	15:35:12	V4UK/20C13-32A-WS	WS24-32A	Rack_001	Connected	16 / 0.0 / 5.0 / 3.0 / 0.0	0.00	0.00	16 / 0.0 / 5.0 / 3.0 / 0.0	0.23	0.03	0.0	0.23	0.03
2014/09/25	15:25:11	V4UK/20C13-32A-WS	WS24-32A	Rack_001	Connected	16 / 0.0 / 5.0 / 3.0 / 0.0	0.00	0.00	16 / 0.0 / 5.0 / 3.0 / 0.0	0.23	0.03	0.0	0.23	0.03
2014/09/25	15:15:10	V4UK/20C13-32A-WS	WS24-32A	Rack_001	Connected	16 / 0.0 / 5.0 / 3.0 / 0.0	0.00	0.00	16 / 0.0 / 5.0 / 3.0 / 0.0	0.23	0.03	0.0	0.23	0.04
2014/09/25	15:05:09	V4UK/20C13-32A-WS	WS24-32A	Rack_001	Connected	16 / 0.0 / 5.0 / 3.0 / 0.0	0.00	0.00	16 / 0.2 / 5.0 / 3.0 / 0.0	0.23	0.02	0.2	0.23	0.02
2014/09/25	14:55:08	V4UK/20C13-32A-WS	WS24-32A	Rack_001	Connected	16 / 0.0 / 5.0 / 3.0 / 0.0	0.00	0.00	16 / 0.1 / 5.0 / 3.0 / 0.0	0.23	0.03	0.1	0.23	0.03
2014/09/25	14:45:07	V4UK/20C13-32A-WS	WS24-32A	Rack_001	Connected	16 / 0.0 / 5.0 / 3.0 / 0.0	0.00	0.00	16 / 0.3 / 5.0 / 3.0 / 0.0	0.23	0.04	0.3	0.23	0.05
2014/09/25	14:35:06	V4UK/20C13-32A-WS	WS24-32A	Rack_001	Connected	16 / 0.0 / 5.0 / 3.0 / 0.0	0.00	0.00	16 / 0.1 / 5.0 / 3.0 / 0.0	0.23	0.03	0.1	0.23	0.03

First / Previous 1 2 3 4 5 6 7 8 9 10 Next / Last

Last 2000 log records.

* Press F11 to enlarge or diminish the screen

< Single Phase PDU Outlet Log >

provides past 2000 log records of each Single Phase PDU's

Outlet

 .
The software will generate an outlet log record every 10 mins.

Single Phase PDU Outlet log

PDU level : 16

Outlet : 01

Date	Time	Model	Name	Status	Amp	kWh	kVA
					Load / Alarm / R. alert / L. alert		
2014/09/25	16:35:19	V4UK/20C13-32A-WS	WS24-32A	ON	- / - / - / -	-	-
2014/09/25	16:25:18	V4UK/20C13-32A-WS	WS24-32A	ON	- / - / - / -	-	-
2014/09/25	16:15:17	V4UK/20C13-32A-WS	WS24-32A	ON	- / - / - / -	-	-
2014/09/25	16:05:15	V4UK/20C13-32A-WS	WS24-32A	ON	- / - / - / -	-	-
2014/09/25	15:55:14	V4UK/20C13-32A-WS	WS24-32A	ON	- / - / - / -	-	-
2014/09/25	15:45:13	V4UK/20C13-32A-WS	WS24-32A	ON	- / - / - / -	-	-
2014/09/25	15:35:12	V4UK/20C13-32A-WS	WS24-32A	ON	- / - / - / -	-	-
2014/09/25	15:25:11	V4UK/20C13-32A-WS	WS24-32A	ON	- / - / - / -	-	-
2014/09/25	15:15:10	V4UK/20C13-32A-WS	WS24-32A	ON	- / - / - / -	-	-
2014/09/25	15:05:09	V4UK/20C13-32A-WS	WS24-32A	ON	- / - / - / -	-	-
2014/09/25	14:55:08	V4UK/20C13-32A-WS	WS24-32A	ON	- / - / - / -	-	-
2014/09/25	14:45:07	V4UK/20C13-32A-WS	WS24-32A	ON	- / - / - / -	-	-
2014/09/25	14:35:06	V4UK/20C13-32A-WS	WS24-32A	ON	- / - / - / -	-	-

First / Previous 1 2 3 4 5 6 7 8 9 10 Next / Last

Last 2000 log records.

* Press F11 to enlarge or diminish the screen

< 5.1 > Single Phase PDU / Outlet Log

< Single Phase Daily kWh Log - PDU >

provides past 2000 daily energy consumption log records of each Single Phase PDU.

The record is logged at 00:00 everyday (+/- 5 mins.)



The daily kWh log will not be recorded at 00:00 if the PDU connected less than 24 hours

Single Phase daily kWh log - PDU

PDU level : 16

Date	Time	Model	Status	Circuit A kWh	Circuit B kWh	Total kWh
2014/12/15	00:00:00	V4UK/20C13-32A-WS	Connected	0.00	0.20	0.20
2014/12/14	00:00:00	V4UK/20C13-32A-WS	Connected	0.00	0.27	0.27
2014/12/13	00:00:00	V4UK/20C13-32A-WS	Connected	0.00	0.23	0.23
2014/12/12	00:00:00	V4UK/20C13-32A-WS	Connected	-	-	-
2014/12/11	00:00:00	V4UK/20C13-32A-WS	Connected	-	-	-

First /Previous 1 2 3 4 5 6 7 8 9 10 Next / Last

Last 2000 log records.

* Press F11 to enlarge or diminish the screen

< Single Phase Daily kWh Log - Outlet >

provides past 2000 daily energy consumption log records of each Single Phase PDU's Outlet .

The record is logged at 00:00 everyday (+/- 5 mins.) .

(Single Phase Outlet Measurement PDU only)

Single Phase daily kWh log - Outlet

PDU level : 16

Outlet : 01

Date	Time	Model	Status	Outlet kWh
2014/12/15	00:00:00	V4UK/20C13-32A-VWS	Connected	-
2014/12/14	00:00:00	V4UK/20C13-32A-VWS	Connected	-
2014/12/13	00:00:00	V4UK/20C13-32A-VWS	Connected	-
2014/12/12	00:00:00	V4UK/20C13-32A-VWS	Connected	-
2014/12/11	00:00:00	V4UK/20C13-32A-VWS	Connected	-

First /Previous 1 2 3 4 5 6 7 8 9 10 Next / Last

Last 2000 log records.

* Press F11 to enlarge or diminish the screen

< 5.1 > Single Phase PDU / Outlet Log

< 63A PDU Log >

provides past 2000 log records of each 63A PDU.

The software will generate a PDU log record every 10 mins.

63A PDU log

PDU level : 04

Date	Time	Model	Name	Location	Status	Bank 1					Bank 4					Total					
						Amp					kWh	Amp					kWh	kVA	Amp	kWh	kVA
						Max.	/ Load	/ Alarm / R. alert / L. alert			/ Load	/ Alarm / R. alert / L. alert					Load				
2015/02/10	02:39:22	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.0	0.0	/ 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/10	02:29:21	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.00	1.0	/ 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/10	02:19:20	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.00		/ 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/10	02:09:19	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.00		/ 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/10	01:59:18	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.00		/ 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/10	01:49:16	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.00		/ 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/10	01:39:15	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.00	0.0	/ 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/10	01:29:14	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.00	0.0	/ 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/10	01:19:13	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.0		/ 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/10	01:09:12	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.0		/ 0.0 / 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/10	00:59:11	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.0		/ 0.0 / 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/10	00:49:10	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.0		/ 0.0 / 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/10	00:39:09	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.0		/ 0.0 / 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/10	00:29:08	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.00		/ 0.0 / 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/10	00:19:06	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.00	1.0	/ 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/10	00:09:05	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.00	0.0	/ 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/09	23:59:04	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.00		/ 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/09	23:49:03	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.00		/ 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/09	23:39:02	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.00		/ 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/09	23:29:01	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.00		/ 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/09	23:19:00	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.00	0.0	/ 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/09	23:09:59	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.00		/ 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				
2015/02/09	22:59:58	V36C13/8C19-63A-W	W44-63A	Rack_004	Connected	16	/ 0.0	/ 13.0 / 0.0 / 0.0	0.06	0.0	0.0	/ 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.11	0.00				

< 63A PDU Outlet Log >

provides past 2000 log records of each Single Phase PDU's Outlet.


The software will generate an outlet log record every 10 mins.

63A PDU Outlet log																
PDU level : 04																
Outlet : 01																
Date	Time	Model	Name	Status	Amp					kWh					kVA	
					Load / Alarm / R. alert / L. alert											
2015/01/31	15:31:44	V36C13/8C19-63A-W	W44-63A	ON	- / - / - / - / -					-					-	
2015/01/30	15:24:41	V36C13/8C19-63A-W	W44-63A	ON	- / - / - / - / -					-					-	
2015/01/30	15:14:40	V36C13/8C19-63A-W	W44-63A	ON	- / - / - / - / -					-					-	
2015/01/30	15:04:39	V36C13/8C19-63A-W	W44-63A	ON	- / - / - / - / -					-					-	
2015/01/30	14:54:38	V36C13/8C19-63A-W	W44-63A	ON	- / - / - / - / -					-					-	
2015/01/30	14:44:37	V36C13/8C19-63A-W	W44-63A	ON	- / - / - / - / -					-					-	
2015/01/30	14:34:35	V36C13/8C19-63A-W	W44-63A	ON	- / - / - / - / -					-					-	
2015/01/30	14:24:33	V36C13/8C19-63A-W	W44-63A	ON	- / - / - / - / -					-					-	
2015/01/30	14:14:31	V36C13/8C19-63A-W	W44-63A	ON	- / - / - / - / -					-					-	

< 5.1 > Single Phase PDU / Outlet Log

< 63A Daily kWh Log - PDU >

provides past 2000 daily energy consumption log records of each 63A PDU. The record is logged at 00:00 everyday (+/- 5 mins.)

 The daily kWh log will not be recorded at 00:00 if the PDU connected less than 24 hours

63A daily kWh log - PDU

PDU level :

04

Date	Time	Model	Status	Bank 1 kWh	Bank 2 kWh	Bank 3 kWh	Bank 4 kWh	Total kWh
2015/02/01	00:00:00	V36C13/8C19-63A-W	Connected	0.03	0.04	0.00	0.00	0.07
2015/01/31	15:31:44	V36C13/8C19-63A-W	Connected	-	-	-	-	-

First / Previous 1 2 3 4 5 6 7 8 9 10 Next / Last

Last 2000 log records.

* Press F11 to enlarge or diminish the screen

< 63A Daily kWh log - Outlet >

provides past 2000 daily energy consumption log records of each 63A PDU's

Outlet

 .

The record is logged at 00:00 everyday (+/- 5 mins.).

(63A Outlet measurement PDU only)

63A daily kWh log - Outlet

PDU level :

04

Outlet :

01

Date	Time	Model	Status	Outlet kWh
2015/02/01	00:00:00	V36C13/8C19-63A-W	Connected	-
2015/01/31	15:31:44	V36C13/8C19-63A-W	Connected	-

First / Previous 1 2 3 4 5 6 7 8 9 10 Next / Last

Last 2000 log records.

* Press F11 to enlarge or diminish the screen

< 5.2 > Three Phase PDU / Outlet Log

< Three Phase PDU Log > provides past 2000 log records of each Three Phase Phase PDU. The software will generate a log every 10 mins.

Three Phase PDU log

PDU level :

01

Date	Time	Model	Name	Location	Status	Amp				Amp			kWh	kVA	Total		
						Max.	Load	Alarm / R		Max.	Load	Alarm / R. alert / L. alert			Amp Load	kWh	kVA
2014/09/25	16:24:32	VP24C13/6C19-32A-W	3PW30-32A	Server_Rack_001R	Connected	L1-2	B1	16 / 0.0 / 13.0 /	10	L3-1	B6	16 / 0.0 / 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.12	0.00
2014/09/25	16:10:24	VP24C13/6C19-32A-W	3PW30-32A	Server_Rack_001R	Connected	L1-2	B1	16 / 0.0 / 13.0 /		L3-1	B6	16 / 0.0 / 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.12	0.00
2014/09/25	16:00:23	VP24C13/6C19-32A-W	3PW30-32A	Server_Rack_001R	Connected	L1-2	B1	16 / 0.0 / 11. /		L3-1	B6	16 / 0.0 / 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.12	0.00
2014/09/25	15:50:22	VP24C13/6C19-32A-W	3PW30-32A	Server_Rack_001R	Connected	L1-2	B1	16 / 0.0 / 13.0 /		L3-1	B6	16 / 0.0 / 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.12	0.00
2014/09/25	15:40:21	VP24C13/6C19-32A-W	3PW30-32A	Server_Rack_001R	Connected	L1-2	B1	16 / 0.0 / 13.0 /		L3-1	B6	16 / 0.0 / 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.12	0.00
2014/09/25	15:30:20	VP24C13/6C19-32A-W	3PW30-32A	Server_Rack_001R	Connected	L1-2	B1	16 / 0.0 / 13.0 /		L3-1	B6	16 / 0.0 / 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.12	0.00
2014/09/25	15:20:19	VP24C13/6C19-32A-W	3PW30-32A	Server_Rack_001R	Connected	L1-2	B1	16 / 0.0 / 13.0 /		L3-1	B6	16 / 0.0 / 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.12	0.00
2014/09/25	15:10:18	VP24C13/6C19-32A-W	3PW30-32A	Server_Rack_001R	Connected	L1-2	B1	16 / 0.0 / 13.0 / 0. /		L3-1	B6	16 / 0.0 / 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.12	0.00
2014/09/25	15:00:16	VP24C13/6C19-32A-W	3PW30-32A	Server_Rack_001R	Connected	L1-2	B1	16 / 0.0 / 13.0 / 0. /		L3-1	B6	16 / 0.0 / 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.12	0.00
2014/09/25	14:50:15	VP24C13/6C19-32A-W	3PW30-32A	Server_Rack_001R	Connected	L1-2	B1	16 / 0.0 / 13.0 /		L3-1	B6	16 / 0.0 / 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.12	0.00
2014/09/25	14:40:14	VP24C13/6C19-32A-W	3PW30-32A	Server_Rack_001R	Connected	L1-2	B1	16 / 0.0 / 13.0 /		L3-1	B6	16 / 0.0 / 13.0 / 0.0 / 0.0	0.00	0.00	0.0	0.12	0.00

First / Previous 1 2 3 4 5 6 7 8 9 10 Next / Last

Last 2000 log records.

* Press F11 to enlarge or diminish the screen

< Three Phase PDU Outlet Log > provides past 2000 log records of each Three Phase Phase PDU's Outlet . The software will generate a log every 10 mins.

Three Phase PDU Outlet log

PDU level :

01

Outlet :

01

Date	Time	Model	Name	Status	Amp			kWh	kVA
					Load	Alarm	R. alert / L. alert		
2014/09/25	16:34:33	VP24C13/6C19-32A-W	3PW30-32A	ON	- / - / - / - / -	-	-	-	-
2014/09/25	16:24:32	VP24C13/6C19-32A-W	3PW30-32A	ON	- / - / - / - / -	-	-	-	-
2014/09/25	16:10:24	VP24C13/6C19-32A-W	3PW30-32A	ON	- / - / - / - / -	-	-	-	-
2014/09/25	16:00:23	VP24C13/6C19-32A-W	3PW30-32A	ON	- / - / - / - / -	-	-	-	-
2014/09/25	15:50:22	VP24C13/6C19-32A-W	3PW30-32A	ON	- / - / - / - / -	-	-	-	-
2014/09/25	15:40:21	VP24C13/6C19-32A-W	3PW30-32A	ON	- / - / - / - / -	-	-	-	-
2014/09/25	15:30:20	VP24C13/6C19-32A-W	3PW30-32A	ON	- / - / - / - / -	-	-	-	-
2014/09/25	15:20:19	VP24C13/6C19-32A-W	3PW30-32A	ON	- / - / - / - / -	-	-	-	-
2014/09/25	15:10:18	VP24C13/6C19-32A-W	3PW30-32A	ON	- / - / - / - / -	-	-	-	-
2014/09/25	15:00:16	VP24C13/6C19-32A-W	3PW30-32A	ON	- / - / - / - / -	-	-	-	-
2014/09/25	14:50:15	VP24C13/6C19-32A-W	3PW30-32A	ON	- / - / - / - / -	-	-	-	-
2014/09/25	14:40:14	VP24C13/6C19-32A-W	3PW30-32A	ON	- / - / - / - / -	-	-	-	-

First / Previous 1 2 3 4 5 6 7 8 9 10 Next / Last


Last 2000 log records.

* Press F11 to enlarge or diminish the screen

< 5.2 > Three Phase PDU / Outlet Log

< Three Phase Daily kWh Log - PDU >

provides past 2000 daily energy consumption log records of each Three Phase PDU. The record is logged at 00:00 everyday (+/- 5 mins.)

 The daily kWh log will not be recorded at 00:00 if the PDU connected less than 24 hours

Three Phase daily kWh log - PDU

PDU level : 01

Date	Time	Model	Status	kWh		kWh		kWh		kWh		Total kWh
2014/12/15	00:00:00	VP24C13/6C19-32A-W	Connected	L1-2	B1	0.00	L1-	-	L3-1	B5	-	0.00
2014/12/14	00:00:00	VP24C13/6C19-32A-W	Connected	L1-2	B1	-	L1-2	-	L3-1	B5	-	-
2014/12/13	00:00:00	VP24C13/6C19-32A-W	Disconnected	L1-2	B1	-	L1-2	-	L3-1	B5	-	-
2014/12/12	00:00:00	VP24C13/6C19-32A-W	Disconnected	L1-2	B1	-	L1-2	-	L3-1	B5	-	-

First /Previous 1 2 3 4 5 6 7 8 9 10 Next / Last

Last 2000 log records.

* Press F11 to enlarge or diminish the screen

< Three Phase Daily kWh Log - Outlet >

provides past 2000 daily energy consumption log records of each Three Phase PDU's

Outlet

 .

The record is logged at 00:00 everyday (+/- 5 mins.).

(3 Phase Outlet measurement PDU only)

Three Phase daily kWh log - Outlet

PDU level : 01

Outlet : 01

Date	Time	Model	Status	Outlet kWh
2014/12/15	00:00:00	VP24C13/6C19-32A-W	Connected	-
2014/12/14	00:00:00	VP24C13/6C19-32A-W	Connected	-
2014/12/13	00:00:00	VP24C13/6C19-32A-W	Disconnected	-
2014/12/12	00:00:00	VP24C13/6C19-32A-W	Disconnected	-

First /Previous 1 2 3 4 5 6 7 8 9 10 Next / Last

Last 2000 log records.

* Press F11 to enlarge or diminish the screen

< 5.3 > Sensor Log

< TH log > provides past 2000 TH log records of each PDU.
The software will generate a TH log record every 10 mins.

TH log

PDU level : 01


					TH 1				TH 2				
					°C		%						
Date	Time	Model	Status	Location	Temp. / Alarm / R. Alert	Humid. / Alarm / R. Alert				Location	Temp. / Alarm / R. Alert	Humid. / Alarm / R. Alert	
2015/02/18	15:13:44	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	51.7 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	54.5 / 65.0 / 0.0	
2015/02/18	15:03:43	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	51.9 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	54.7 / 65.0 / 0.0	
2015/02/18	14:53:42	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	52.2 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	54.9 / 65.0 / 0.0	
2015/02/18	14:43:41	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	52.4 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	55.1 / 65.0 / 0.0	
2015/02/18	14:33:40	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	52.6 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	55.3 / 65.0 / 0.0	
2015/02/18	14:23:39	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	52.8 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	55.6 / 65.0 / 0.0	
2015/02/18	14:13:38	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	53.0 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	55.8 / 65.0 / 0.0	
2015/02/18	14:03:37	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	53.1 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	55.9 / 65.0 / 0.0	
2015/02/18	13:53:36	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	53.1 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	55.9 / 65.0 / 0.0	
2015/02/18	13:43:35	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	53.1 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	56.0 / 65.0 / 0.0	
2015/02/18	13:33:34	V12C13/8C19-16A-W	Connected	Front_Top	23.4 / 35.0 / 0.0	53.3 / 65.0 / 0.0				Rear_Top	22.7 / 35.0 / 0.0	56.2 / 65.0 / 0.0	
2015/02/18	13:23:33	V12C13/8C19-16A-W	Connected	Front_Top	23.4 / 35.0 / 0.0	53.4 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	56.3 / 65.0 / 0.0	
2015/02/18	13:13:32	V12C13/8C19-16A-W	Connected	Front_Top	23.4 / 35.0 / 0.0	53.3 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	56.3 / 65.0 / 0.0	
2015/02/18	13:03:31	V12C13/8C19-16A-W	Connected	Front_Top	23.4 / 35.0 / 0.0	53.2 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	56.2 / 65.0 / 0.0	
2015/02/18	12:53:30	V12C13/8C19-16A-W	Connected	Front_Top	23.4 / 35.0 / 0.0	53.0 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	56.0 / 65.0 / 0.0	
2015/02/18	12:43:29	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	52.9 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	55.9 / 65.0 / 0.0	
2015/02/18	12:33:28	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	52.7 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	55.7 / 65.0 / 0.0	
2015/02/18	12:23:27	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	52.5 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	55.5 / 65.0 / 0.0	
2015/02/18	12:13:26	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	52.4 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	55.3 / 65.0 / 0.0	
2015/02/18	12:03:25	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	52.3 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	55.2 / 65.0 / 0.0	
2015/02/18	11:53:24	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	52.3 / 65.0 / 0.0				Rear_Top	22.7 / 35.0 / 0.0	55.1 / 65.0 / 0.0	
2015/02/18	11:43:22	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	52.2 / 65.0 / 0.0				Rear_Top	22.7 / 35.0 / 0.0	55.1 / 65.0 / 0.0	
2015/02/18	11:33:21	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	52.2 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	55.0 / 65.0 / 0.0	
2015/02/18	11:23:20	V12C13/8C19-16A-W	Connected	Front_Top	23.3 / 35.0 / 0.0	52.1 / 65.0 / 0.0				Rear_Top	22.6 / 35.0 / 0.0	54.9 / 65.0 / 0.0	

Part VI. Report

< **Report** > provides monthly report for **PDU log** , **Outlet log** , **TH Sensor log** , **Daily kWh log** & **Event log** which can be exported in CSV format.


Please follow the steps below to export the log category you want :

Step 1. Select “ **Category** ” , “ **Period** ” & “ **Target** ”



Step 2. Click “ **Apply** ” & Click “ **OK** ” from the pop up window

Step 3. Right Click the file name below & Select “ **Save target as** ” to download the log file



Step 4. Click “ **Close** ” to complete or “ **Open** ” to view the content of log file

..... **Complete**

Part VII. SNMP

< 7.1 > SNMP Setup via IP Dongle

< SNMP Setup >

The IP Dongle can manage all PDUs in a single daisy-chain up to 16 PDUs via SNMP v2c (Simple Network Management Protocol).



Only IP Dongle model : IPD-04-S or IPD-H04-S can support SNMP

(I). Accessing MIB Files

Step 1. Click the following link to go to the mangement software download page :
<http://www.austin-hughes.com/downloads/IPDL/MIB.html>

Step 2. Select the appropriate MIB file of the PDU series

(II). Enabling SNMP Support

The following procedure summarizes how to enable the IP Dongle for SNMP support.

Step 1. Connect the IP Dongle to a computer. (Please refer to < 2.2 > IP Dongle Configuration)

Step 2. Open the Internet Explorer (I.E.) version 8.0 or above


Step 3. Enter the configured IP Dongle address into the I.E. address bar.
Default IP address is “ **192.168.0.1** “

Step 4. Enter “ **Login name** “ & “ **Password** “. Default login name & password are “ **00000000** “

A screenshot of a web-based login interface. It features two text input fields: the first is labeled 'Login name' and the second is labeled 'Password'. Below these fields are two buttons: 'Login' on the left and 'Cancel' on the right. The entire interface is enclosed in a thin black rectangular border.

< 7.1 > SNMP Setup via IP Dongle

Step 5. Select the **SNMP** from the left navigation



Step 6. The **SNMP** Settings window appears as below:

A screenshot of the 'SNMP' settings window. The window has a title bar 'SNMP'. It contains several sections: 'SNMP agent' with radio buttons for 'Enable' (selected) and 'Disable'; 'SNMP polling' with input fields for 'Read community' (public) and 'Write community' (private); 'SNMP traps' with a dropdown menu set to 'v2Trap'; and 'Management station' with input fields for 'Station IP' (138.168.2.225), 'Trap port' (162), and 'Trap community' (private). At the bottom, there are 'Apply' and 'Cancel' buttons. The 'Apply' button is circled in red.

Step 7. Click “ **Enable** ” in “ **SNMP Agent** ” to start the SNMP agent service

Step 8. Input “ **Read Community** “. Default is “ **public** ”

Step 9. Input “ **Write Community** “. Default is “ **private** ”

Step 10. Select “ **disabled** ” or “ **V2Trap** ” in “ **SNMP Traps** ”

! If select “ **V2Trap** ”, please input IP address of the SNMP management station in “ **Station IP:** ”

Step 11. Click “ **Apply** ” to finish the SNMP settings

..... **Complete**

< 7.2 > IP Dongle Firmware Upgrade

< Firmware Upgrade >

For function enhancement of IP dongle WEB UI or fail to search the PDU, please take the following steps to remotely upgrade the IP Dongle firmware :

Step 1. Click the following link to go to the mangement software download page :

<http://www.austin-hughes.com/downloads/IPDL/IPDfirmware.html>

Step 2. Select the appropriate IP Dongle firmware file of the PDU series


Step 3. Connect the IP Dongle to the computer.

Step 4. Open the Internet Explorer (I.E.) version 8.0 or above

Step 5. Enter the configured IP Dongle address into the I.E. address bar.


Default IP address is “ **192.168.0.1** “

Step 6. Enter “ **Login name** “ & “ **Password** “. Default login name & password are “ **00000000** “




A login form with two input fields: "Login name" and "Password". Below the fields are two buttons: "Login" and "Cancel".

Step 7. Select the Firmware from the left navigation



< 7.2 > IP Dongle Firmware Upgrade

Step 8. The firmware upgrade window appears as below :



Firmware

Device information

Device name	InfraPower
Device IP address	192.168.1.82
Device MAC address	C8:EE:08:00:18:94
Firmware version	V2311S
Hardware revision	2.0

Upgrade firmware

File path

Warning Upgrading firmware may take a few minutes,
please don't turn off the power or press the reset button.

Step 9. Click “ **Browse** ” and select the firmware file (xxx.img) from the specific path in the pop up window and Click “ **Open** ”

Step 10. Click “ **Upgrade** ” to start the upgrade process. It takes a few minutes to complete.

Step 11. Once complete, UI will return to the login page.

Part VIII. FAQ

< 8.1 > Management Software



1. Is IPM-04 management software free of charge ?

Yes.

2. What is InfraPower Manager ?

The InfraPower Manager IPM-04 is a Windows based system to consolidate management of max. **800 PDUs** via **50 IP dongles**, using a simple web interface which monitors and controls Single & 3 Phase W series PDUs.

- SNMP Capability via IP Dongle
- Outlet switch On/Off and scheduling
- Outlet level kWh & amp measurement
- Temp-Humid monitoring
- Graphic user interface
- PDU & outlet reporting (kWh / Amp / Event / Temp & Humid)

3. Which OS platform does IPM-04 support ?

- MS Windows XP Professional with SP3 (32bit only)
- MS Windows 7 Professional with SP1
- MS Windows 7 Ultimate with SP1
- MS Windows Server 2003 R2 Standard Edition with SP2
- MS Windows Server 2008 Standard Edition SP2
- MS Windows Server 2008 R2 Standard Edition SP1



Ensure the user logs in as a member of “Administrators” Group before IPM-04 Installation and execution.

4. What are the default ports used in the IPM-04 ?

- UTP port : 8890 for searching IP Dongle
- TCP port : 4000 for IP Dongle communication
- TCP port : 80 for HTTP
- TCP port : 25 for email alarm service (can be changed by user)

5. Why can't I access the login page ?

- If the web service is started & the port of web server is open in firewall setting

6. Why can't I login remotely ?

- If the login name & password is correct

7. Which database does the IPM-04 support ?

PostgreSQL

8. What is the PostgreSQL default password for IPM-04 ?

1qaz2WSX

9. How can I receive alarm email and get full log report ?

Ensure that IPM-04 is executed and the alarm server is configured properly and being enabled.

< 8.1 > Management Software

10. What is the default user name & login password of IPM-04 ?

Default user name “ admin ” / Default login password “ 00000000 ”

11. What is the command password of IPM-04 ?

- Each IP Dongle group has its command password (Default “ 00000000 ”) .
- For security, it will be requested for any PDU configuration and control.
- Only administrator can set command password.
- The passwords are disabled or enabled, same or different subject to the administrator’s management.

12. Is it possible to increase PDU from 800 & IP Dongle group from 50 ?

Yes, but custom management software & service charges required.

13. Is it possible to increase the concurrent user from 5 ?

Yes, but custom management software & service charges required.

14. Can I manage W series PDUs from different workstations ?

Yes, max. 5 concurrent login users from different workstations.

15. Why UI shows PDU / PDUs disconnection ?

- the PDU is power OFF or
- duplicate the PDU level no. or
- cable loose / defective

- the IP Dongle fails
Refer to < 8.2 > IP Dongle

- the W Meter fails
Refer to < 8.3 > W Meter

- the power module fails
Refer to < 8.4 > Power Module

< 8.2 > IP Dongle



1. What is the IP Dongle ?

The IP Dongle, with patented hot-plug & field replaceable design and SNMP function, provides a simple and economical way to consolidate management of max. 16 pcs of W series Single & 3 Phase PDUs via a single network IP address to save IP address cost.

2. Does IP Dongle have a built-in UI ?

Yes, a built-in UI provides a general remote monitoring & control for cascaded PDUs. However, this built-in UI can only manage up to 16 PDUs in a daisy chain, no any reporting, event & log. If need a complete monitoring & control AND a log & reporting for some hundred PDUs, the free IPM-04 PDU management software is absolutely required.

3. Can I use the built-in dongle UI and IPM-04 management software simultaneously?

No, only either one.

4. Is the IP Dongle essential to IPM-04 management software ?

Yes, the software can't run without IP Dongle

5. Is the IP Dongle essential to SNMP function ?

Yes, absolutely.

6. What is default setting of IP Dongle ?

The default IP setting is as below :

IP address :	192.168.0.1
Subnet mask :	255.255.255.0
Gateway :	192.168.0.254

7. What is the IP setup utilities?

This is a windows application used to assign the IP address of IP Dongle.
Please find the link below :

<http://www.austin-hughes.com/support/utilities/infrapower/IPdongleSetup.msi>

8. What are the default ports used in IP setup utilities ?

- UTP port : 8880, 8881, 8882, 8883, 8884, 8888, 8889, 8890 & 8891

9. Does the IP Dongle support DHCP (Dynamic Host Configuration Protocol)?

No, the IP Dongle only works with static IP-address.

10. Will the reset of IP Dongle affect the power to the outlets ?

No, the IP Dongle operates on a separate circuit, so the power to the outlets will remain unchanged.

< 8.2 > IP Dongle

11. What are the symptoms if the IP Dongle fails ?

- UI shows IP Dongle disconnection and users fail to access the whole cascaded PDUs
- Green LED off of IP Dongle

12. Why the IP Dongle fails to work ?

- the IP Dongle itself fails or
- the 1st level W Meter fails or
- the 1st level Power Module fails or
- cable loose or defective between IP Dongle and the network device

13. How can I replace a failed IP Dongle ?

Download the guide below to replace the IP Dongle :

<http://www.austin-hughes.com/support/replacementguide/infrapower/RG-IP-W-IP-Dongle.pdf>

14. Does the IP dongle have firmware built-in ?

Yes

15. How can I get the updated IP dongle firmware ?

Please find the link below :

<http://www.austin-hughes.com/download/IPDL/IPDfirmware.html>

16. Can I remotely update the IP dongle firmware ?

Yes.

Download the guide below to update the firmware accordingly :

<http://www.austin-hughes.com/support/upgradeguide/infrapower/UG-IP-IP-Dongle.pdf>

< 8.3 > W Meter



1. What are features of the W Meter ?

- Support single & 3Phase PDU and they can be inter-cascaded in a single daisy chain
- Support switched PDU and outlet amp + kWh measurement
- Simply connect 1 x IP Dongle to access up to 16 PDUs to save IP network address
- SNMP Capability via IP Dongle
- Sensor port x 2
- 2.8" color LCD featured w/ touchscreen
- Built-in buzzer will sound when circuit or bank Amp over alarm setting
- Field replaceable design allows meter replacement without PDU power interruption

2. What is the default PDU level ?

Level 16

3. What is the default outlet status of Switched PDU ?

ON

4. If one of the cascaded PDU W Meter fails, will it affect the data transmission among PDUs in the same daisy chain ?

No , the meter design prevents this from happening.

5. If one of the cascaded W series PDU (meter) loses power, will it affect the data transmission among PDUs in the same daisy chain ?

Yes, if the 1st level PDU loses power.

No , if NOT the 1st level PDU loses power.

6. What is the maximum cabling distance between two cascaded W series PDUs ?

Up to 20 meter (66 feet) via CAT. 5 / 6 cable.

7. What are the symptoms if the W Meter fails ?

- if the W Meter PDU is one of that among the 2nd to last level, UI shows PDU disconnection and users fail to access this PDU
- if the W Meter PDU is the 1st level, UI shows IP Dongle disconnection and users fail to access the whole cascaded PDUs
- W Meter no display

8. Why the W Meter fails to work ?

- the W Meter itself fails or
- the Power Module fails and can't supply power to W Meter so the W Meter fails to work or
- the Power Module IC defective and causes W Meter has no data return or
- the LAN cable loose or defective

9. How can I replace a failed W Meter ?


Download the guide below to replace the W Meter :

<http://www.austin-hughes.com/support/replacementguide/inrapower/RG-IP-New-W-Meter.pdf>

< 8.3 > W Meter

10. How accurate is the energy measurement on W Meter ?

The W Meter have an accuracy of +/- 1% of reading across the entire power and outlets energy measurement compliant with IEC 62053/ANSI C12.20 Standards

- 
- Ampere - squelched to 0A under 0.3A
 - Accuracy is not defined below 0.3A.


Functional Specifications - Metering	
Input Metering Range	0.3 to Rated Input Current
Outlet Metering Range	0.3 to 16.0A
Ampere Accuracy (A)	+/- 1%
Voltage Accuracy (V)	+/- 1%
Power Accuracy (kW)	+/- 1%
Energy Accuracy (kWh)	+/- (1%)*hours

11. Does the W meter have firmware built-in ?

Yes

12. What can I do if the W Meter turns white ?

- Use a pin to press the reset button
- If the symptom still persists, call your dealer for support



< 8.4 > Power Module

1. What is feature of the Power Module ?

- convert AC to DC for W Meter, IP Dongle & outlet control module
- field replaceable design allows replacement without PDU power interruption

2. How affect the W Meter if the Power Module fails ?

It will cause the meter fails to work as below :

- if the W Meter PDU is one of level among the 2nd to the last, UI shows PDU disconnection and users fail to access this PDU
- if the W Meter PDU is the 1st level, UI shows IP Dongle disconnection and users fail to access the whole cascaded PDUs
- W Meter no display and / or no data return

3. How affect the switched & measurement WS / WSi / Wi PDU if the Power Module fails ?

- lose outlet On/Off control and outlet amp & kWh measurement
- but outlet can still supply power to device

4. Why the Power Module fails to work ?

- the power module itself fails

5. How can I replace a failed Power Module ?

Download the guide below to replace the Power Module :

<http://www.austin-hughes.com/support/replacementguide/infrapower/RG-IP-W-Power-Module.pdf>



< 8.5 > Outlet Control Module

1. How many types of Outlet Control Module ?

The outlet control module is a built-in PCB and NOT a hot-swapped & field replaceable design.

- switched & measurement module for WSi switched & outlet level measurement PDU
- outlet measurement module for Wi outlet level measurement PDU
- switched module for WS switched PDU

2. How affect the switched & measurement WS / WSi / Wi PDU if the Outlet Module fails ?

- lose outlet On/Off control and outlet level measurement
- but outlet can still supply power to device

3. Why the outlet control module fails to work ?

- the outlet control module itself fails

4. How can I replace a failed Outlet Control Module ?

No, not like W Meter & Power Module, Outlet Control Module is NOT hot-swapped & field replaceable design. You have to replace the whole PDU.

5. How can I replace a failed PDU ?

Download the guide below to replace the PDU :

<http://www.austin-hughes.com/support/replacementguide/infrapower/RG-IP-New-W-PDU.pdf>

< 8.6 > TH Sensors & Others

TH sensors

1. **How accurate is the Temp. & Humid. sensor ?**
 $\pm 1^{\circ}\text{C}$ (typical) & $\pm 4.5\%$ RH (typical)
2. **How accurate is the Temp. sensor ?**
 $\pm 1.5^{\circ}\text{C}$ (typical)
3. **What is the default TH setting ?**
Default : Deactivate
4. **Is the TH sensor plug-n-play ?**
Yes, but only for the local meter display.
No, for management software UI. You have to activate the sensor in < TH Sensor >.
Note : never activate if no sensor connection

Others

1. **Will the PDU settings remain unchanged after power OFF ?**
Yes, the settings will remain unchanged such as PDU & Outlet Name, Location, Alarm amp., Low alert amp.
2. **Does the InfraPower PDU has the over ampere protection ?**
Yes, the optional resettable fuse and circuit breaker available.
3. **What is the standard inlet cable length of InfraPower PDU ?**
3 meter (9.9 feet)
4. **Where can I find the Catalogue / User manual / Model list / Wire diagram of InfraPower PDUs ?**
Please visit the www.austin-hughes.com
5. **How can we get a further support?**
Please send the email to support@infra-power.com or sales@infra-power.com

The company reserves the right to modify product specifications without prior notice and assumes no responsibility for any error which may appear in this publication.

All brand names, logo and registered trademarks are properties of their respective owners.

Copyright 2015 Austin Hughes Electronics Ltd. All rights reserved.